



Dunk Tank

Installation Procedures

Setup

1. Select a level area for set up.
2. Slowly lift up and set tank upright. (Be careful not to drop tank onto its bottom.)
3. Swing wing out into position. NOTE: The wing MUST BE STRAIGHT out from the tank frame. If it is at an angle the trigger will not work properly. Lower the two stabilizing rods on the bottom of the wing so the wind does not move it as this will cause the target arm to jam.
4. Check drain plug to make sure it is tight and then fill tank to the top with water (approx. 500 gallons).
5. Place arm into the trigger mechanism. Put the other end through the hole in the canvas. Make sure the arm pin drops into the pivot point on the side of the frame. Insert the target into the threaded end of the arm turn to tighten.
6. With you hand "test" the target to see that it works properly. Check to ensure that the seat latch is engaging properly.
7. REVIEW SAFETY RULES WITH ALL PARTICIPANTS!

Operation

1. Check to see that seat is properly locked and is released when the target is pressed. Be sure to show this operation to the person who will be on the tank as they will need to know how to reset the seat and trigger mechanism each time it is released, before they get back onto the seat. Instruct them to use the grip handles for support when climbing up out of the tank. Also, be sure instruct the dunkee on the proper use of the seat safety latch, which is located behind the seat, to keep it secure until they are ready to be dunked.
Please remind the dunkee to keep their hands on their knees and sit forward on the seat.
2. Use ONLY the balls that came with the EASY DUNKER.
3. Monitor water level to keep it full.
- 4.

Operating Procedures

- Easy Dunker must always have an adult operator on duty when in use.
- When tank is going to be unattended, always drain water. NEVER LEAVE A DUNK TANK FILLED WITH WATER UNATTENDED!
- Cordon off a "danger zone" in front of, to the sides of, and behind the tank. Keep people out of the zone to avoid getting hit by an errant or deflected throw. Children should never be allowed inside this "danger zone."
- Never place the dunk tank on a platform or stage. (NOTE: When filled the dunk tank weighs over 4,500 pounds.)
- Keep Easy Dunker away from electricity.
- Keep water level to at least 8" from the top of the tank.
- Only one person at a time should be allowed on the seat or in the tank.
- Keep all non-swimmers, anyone less than 5' tall, or over 250 pounds off of the tank.
- Anyone with medical conditions which may place limitations on their physical exertion (such as, but not limited to: heart condition, pregnancy, back injury, etc.) should stay off of the dunk tank.
- To keep from slipping, the dunkee must always wear rubber sole shoes.
- Before (and each time the dunkee climbs onto the seat, they must first make sure the seat is securely locked in place and that the safety latch is engaged.
The dunkee should use the handles to assist in climbing out of the tank and for getting back up onto the seat after being dunked. However, the dunkee must not hold onto the handles while being dunked.
- The dunkee must move toward the front of the tank when coming up out of the water to avoid hitting their head on the seat.
Never use hard balls.
Never stand on seat.
When being dunked, the dunkee must keep hands on knees and sit forward on the seat.
- Do not allow anyone to hit target with hands.
- Do not operate Easy Dunker during a storm.

I HAVE READ AND UNDERSTAND THE INSTALLATION AND OPERATING PROCEDURES.

Signature

Date